




OPERATOR HEAD PARTS



LSO & LCO



LDO




LSO, LDO, LCO

GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST


ITEM #	REPLACEMENT PART	PART #
1	REAR LSO & LCO END COVER (WITH LABELS)	HAE00041
2	MAIN LSO COVER (WITH LABELS)	HAE00026
3	MAIN LCO COVER (WITH LABELS)	HAE00042
4	FRONT LSO COVER (WITH LABELS)	HAE00028
5	FRONT LCO COVER (WITH LABELS)	HAE00043
6	LSO & LCO LENS COVER (FITS BOTH ENDS)	220918
7	LSO MOTOR	220919
8	LCO MOTOR	220919
9	1/3 HP LDO COVER (WITH LABELS)	HAE00011
10	1/2 HP LDO COVER (WITH LABELS)	HAE00012
11	LDO LENS COVER	217645
12	LDO MOTOR	217881
13	CONTROL BOARD (LOGIC/RECEIVER/TORQUE)	HAE00040
14	LAMP SOCKET ASSEMBLY	218014-02
15	1/3 HP CAPACITOR (43-53 MFD) <i>FOR LD033 ONLY</i>	219109
16	1/2 HP CAPACITOR (53-64 MFD) <i>FOR LD050 ONLY</i>	219110
17	3/4 HP CAPACITOR (65 MFD) <i>FOR LC075 ONLY</i>	232168
18	HELICAL AND WORM GEARS (WITH GREASE)	HAE00047
19	HELICAL GEAR (WITH GREASE)	HAE00048
20	LIMIT SWITCH ASSEMBLY	HAE00004

GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

DC OPERATOR HEAD PARTS







LDCO 800, 801



LDCO 850, 852, 841, 863B

ITEM #	REPLACEMENT PART	PART #
1	LDCO CONTROL BOARD, BBU COMPATIBLE (800/801)	HAE00077
2	LDCO FRONT COVER (WITH LABEL) (800/801)	HAE00051
3	BATTERY BACKUP UNIT (800/801)	BBU
4	LDCO ENCODER BOARD (800/801/841/850/852/863B)	HAE00058
5	LDCO MAIN COVER (WITH LABELS) (800/801)	HAE00052
6	LDCO LIGHT LENS (800/801/850)	228152
7	LDCO MOTOR (WITH ENCODER) (800/801/841/850/852/863B)	HAE00057
8	KIT, PCBA, LDCO (841/850/852/863B)	HAE00075
9	TRANSFORMER (841/850/852/863B)	10012046
10	COVER, MAIN (841/863B)	HAE00073
11	BRACKET KIT (852)	10016007
12	REPLACEMENT BATTERY, 12V (841/850/852/863B)	BATT54
13	BATTERY AND HOUSING (841/850)	BATT54BOX
14	BATTERY HOUSING (850/863B)	10015410-004
15	BATTERY HOUSING (852)	10015932-001
16	LED PANEL (841/850)	10014504-01
17	LED PANELS (852)	RP9004
18	LED PANELS (863B)	RP9005

DC OPERATOR HEAD PARTS




LINEAR 661

GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

ITEM #	REPLACEMENT PART	PART #
1	F/G CONTROL BOARD, LINEAR600	HAE00082
2	F/G ASSY, MOTOR W/ENCODER, LINEAR600	HAE00083
3	F/G ASSY, LIGHT LENS, LINEAR600	HAE00084
4	F/G POWER SUPPLY, LINEAR600 BATT54	HAE00085


MISCELLANEOUS OPERATOR PARTS




GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

ITEM #	REPLACEMENT PART	PART #
1	DOOR ARM - STRAIGHT	227966
2	DOOR ARM - BENT	227967
3	SAFETY BEAM SENDER & RECEIVER (WITH WIRE)	HAE00087
4	COMPLETE HARDWARE KIT	220205-02
5	WALL STATION (LDO/LSO/LCO/800/801)	HAE00001
6	WIFI WALL STATION (UNIVERSAL REPLACEMENT FOR LDCO841 /850/852/863, LINEAR600)	HAE00080
7	WIRE KIT (15 SETS OF WIRE AND CLIPS)	HAE00044
8	WIRE CLIP KIT (100 CLIPS)	HAE00019
9	GEL CAP KIT (100 PIECES)	HAE00020

OPERATOR RAIL PARTS



HBT BELT DRIVE RAILS



HCT and HCI CHAIN DRIVE RAILS

GARAGE DOOR OPERATOR REPLACEMENT PARTS LIST

ITEM #	REPLACEMENT PART	PART #
1	HBT DRIVE SPROCKET	220499
2	HBT PULLEY AND BRACKET	218954-03
3	HBT INNER SLIDE ASSEMBLY	HAE00022
4	TROLLEY ASSEMBLY	218189-01
5	7 FOOT BELT ASSEMBLY	HAE00023
6	8 FOOT BELT ASSEMBLY	HAE00033
7	DRIVE SPROCKET HOLDER AND BELT CLAMP <i>BELT CLAMP FOR USE ON HBT BELT RAILS ONLY</i>	HAE00049
8	HCT DRIVE SPROCKET	217436
9	HCI DRIVE SPROCKET	227653
10	HCT PULLEY AND BRACKET	HAE00014
11	HCT TURNBUCKLE ASSEMBLY	HAE00013
12	HCT INNER SLIDE ASSEMBLY	HAE00018
13	CENTER SUPPORT BRACKET	CSB
14	7 FOOT CHAIN ASSEMBLY	HAE00015
15	8 FOOT CHAIN ASSEMBLY	HAE00032
16	10 FOOT CHAIN ASSEMBLY	HAE00017
17	12 FOOT CHAIN ASSEMBLY	HAE00046

Customer Service

(800) 421-1587

Monday – Friday / 8am – 7pm EST

Nice North America LLC

5919 Sea Otter Place, Suite 100

Carlsbad, CA 92010